3/6/2020 TestOut LabSim

### Lab Report: 3.12.5 Upgrade a Video Card

#### **Your Performance**

Your Score: 3 of 5 (60%) Pass Status: Not Passed

Elapsed Time: 5 minutes 26 seconds Required Score: 100%

# **Task Summary**

### Actions you were required to perform:

Pa Disconnect the monitor from the current video adapter

Pa Remove the current VGA video adapter from the computer

In Install the video card with HDMI output into the computer

Pa Connect the new HDMI video card to the monitor with an HDMI cable

In Set the resolution to 1920x1080

## **Explanation**

In this lab, your task is to complete the following:

- Disconnect the monitor from the onboard video card.
- Install the video card with the HDMI connection. HDMI is an interface used by monitors and digital televisions for high-definition content. When installing the video card, connect the PCIe power connector to the video card.
- Connect the computer to the monitor using an HDMI cable.
- In Windows, configure a resolution of 1920x1080 for full HD content. Even though the monitor supports a higher resolution, this is the resolution for HD content.

# Complete this lab as follows:

- 1. Disconnect the monitor from the current video card as follows:
  - a. Above the computer, select **Back** to switch to the back view of the computer.
  - b. Above the monitor, select **Back** to switch to the back view of the monitor.
  - c. Drag the **DB-15 Connector** from the computer to the Workspace area.
  - d. Drag the **DB-15 Connector** from the monitor to the Shelf.
- 2. Remove the current video card from the computer as follows:
  - a. Above the computer, select **Motherboard** to switch to the motherboard view of the computer.
  - b. Drag the **VGA Video Adapter** from the computer to the Shelf.
- 3. Install a new video card as follows:
  - a. For each video card on the Shelf, select **Details**.
  - b. Select **Connectors** for the video card to find the one with the HDMI connection.
  - c. Close the Details window.
  - d. Drag the **HDMI video adapter** from the Shelf to an open PCI Express slot on the motherboard.
  - e. Select the **power supply** to provide power to the video card. The video card requires an additional PCIe power connection.
  - f. Under Selected Component, drag a 6-pin PCIe power connector to the power port on the right side of the video card.
- 4. Connect the computer to the monitor as follows:
  - a. Above the computer, select **Back** to switch to the back view of the computer.
  - b. On the Shelf, expand Cables.
  - c. Select the **HDMI cable**.
  - d. Under Selected Component, drag an **HDMI Connector** to the HDMI port on the video card.
  - e. Under Selected Component, drag an HDMI Connector to the HDMI port on the monitor.
  - f. Above the computer, select **Front** to switch to the front view of the computer.
  - g. Above the monitor, select **Front** to switch to the front view of the monitor.
  - h. Click the **power** button for the computer.
- 5. Modify the screen resolution as follows:

3/6/2020 TestOut LabSim

- a. After Windows loads, right-click the **desktop** and select **Display settings**.
- b. Under Resolution, select 1920x1080.
- c. Select **Keep changes**.