#### Lab Report

#### **Your Performance**

Your Score: 5 of 5 (100%) Pass Status: Pass Elapsed Time: 1 minute 36 seconds Required Score: 100%

# **Task Summary**

#### Actions you were required to perform:

- Disable the Broadcom network adapter
- Enable the Realtek network adapter
- Update the driver for the Realtek network adapter
- Roll back the driver for the video card
- Move the Ethernet cable to the integrated network port on the motherboard

## **Explanation**

In this lab, your task is use Device Manager to complete the following:

- The new network card you installed isn't working as expected (speed is only 1 Mbps). Until you can figure out what the problem is, disable the Broadcom network adapter and enable the Realtek network adapter.
- To make sure the network adapter has the latest drivers, update the driver for the Realtek network adapter by searching Microsoft Update.
- You recently updated the driver for your video card. However, the system experiences periodic crashes that you suspect are caused by the new driver. Roll back the driver to a previous version.
- Move the Ethernet cable to the integrated network port on the motherboard.

### Complete the following steps:

- 1. Right-click Start and select Device Manager.
- 2. Expand **Network adapters**.
- 3. Disable the network adapter as follows:
  - a. Right-click Broadcom NetXtreme 57xx Gigabit Controller and select Disable device.
  - b. Click Yes.
- 4. Right-click Realtek 8169 and select Enable device.
- 5. Update the driver as follows:
  - a. Right-click Realtek 8169 and select Update driver.
  - b. Select Search automatically for updated driver software.
  - c. After the driver is installed, click **Close**.
- 6. Roll back the video card driver as follows:
  - a. Expand **Display adapters**.
  - b. Right-click ATI Radeon HD 3300 and select Properties.
  - c. Select the **Driver** tab.
  - d. Select Roll Back Driver.
  - e. Click Yes.
  - f. Click **OK**.
- 7. Move the Ethernet cable to the integrated network port on the motherboard as follows:
  - a. From the top navigation tabs, select **Support Office**.
  - b. Above the computer, select **Back** to switch to the back view of the computer.
  - c. Drag the Ethernet connector from the PCIe NIC to the integrated network port on the motherboard.