1/21/2020 Simulation Viewer

## Lab Report

## **Your Performance**

Your Score: 1 of 3 (33%) Pass Status: Not Passed Elapsed Time: 6 minutes 6 seconds Required Score: 100%

## **Task Summary**

Change admin username and password Hide Details

Admin name: WxAdmin Password: ZDAdminsOnly!\$

Enable MAC address filtering **Hide Details** 

> ACL name: Allowed Devices Allowed Device: 00:02:2D:23:56:89 Allowed Device: 00:02:2D:44:66:88 allowed Device: 00:18:DE:01:34:67 Allowed Device: 00:18:DE:22:55:99

X Configure access controls Hide Details

> Device access policy name: NoGames Deny OS type: Gaming

## **Explanation**

Configure the security features on your wireless controller as follows:

- 1. Change the admin username and password as follows:
  - a. From the taskbar, open **Internet Explorer**.
  - b. Maximize Internet Explorer.
  - c. Type **192.168.0.6** and press **Enter**.
  - d. Enter the *username*.
  - e. Enter the *password*.
  - f. Select Login.
  - g. From the top, select the **Administer** tab.
  - h. Make sure Authenticate using the admin name and password is selected.
  - i. In the Admin Name field, enter the new *username*.
  - j. In the Current Password field, enter the current *password*.
  - k. In the New Password field, enter the new *password*.
  - l. In the Confirm New Password field, enter the new *password*.
  - m. On the right, select **Apply**.
- 2. Enable MAC address filtering as follows:
  - a. From the top, select the **Configure** tab.
  - b. From the left menu, select Access Control.
  - c. Expand L2-L7 Access Control.
  - d. Under L2/MAC address Access Control, select Create New.
  - e. In the Name field, enter Allowed Devices.
  - f. Under Restriction, make sure Only allow all stations listed below is selected.
  - g. Enter a MAC address.
  - h. Select Create New.
  - i. Repeat step 2g–2h for each MAC address you would like to add to the ACL.
  - j. Click **OK**.

- 3. Configure access controls as follows:
  - a. In Access Control, expand **Device Access Policy**.
  - b. Select Create New.
  - c. In the Name field, enter NoGames.
  - d. Select Create New.
  - e. In the Description field, enter **Games**.
  - f. In the OS/Type drop-down list, select **Gaming**.
  - g. In the Type field, select **Deny**.
  - h. Under Uplink, make sure **Disabled** is selected.
  - i. Under Downlink, make sure **Disabled** is selected.
  - j. Click Save.
  - k. Click **OK**.