2/24/2020 Simulation Viewer

### Lab Report

#### **Your Performance**


Your Score: 2 of 3 (67%) Pass Status: Not Passed

Elapsed Time: 6 minutes 36 seconds Required Score: 100%

# **Task Summary**

### Actions you were required to perform:

- Install the Intel 1151 motherboard
- Connect system case connectorsHide Details



✓ Connect power supply connectorsHide Details

- Connect the main motherboard power
- Connect the CPU power

# **Explanation**

In this lab, your task is to complete the following:

- Select and install the motherboard that meets the scenario requirements.
- Connect the following computer case cables:
  - Power switch
  - 3-1 pin Power LED
  - Case speaker
  - HDD LED
  - Front fan
  - Rear fan
  - USB 2.0
  - USB 3.0
  - Audio
- Connect the following connectors from the power supply:
  - Main motherboard power
  - CPU power

#### Complete this lab as follows:

- 1. Select and install the motherboard as follows:
  - a. On the Shelf, expand **Motherboards**.
  - b. For a motherboard, select **Details**.
  - c. Select the **Specifications** tab.
  - d. Read the **motherboard documentation** to identify the supported features.

2/24/2020 Simulation Viewer

- e. Repeat steps 2–4 to identify the features for each motherboard.
- f. After you have found the motherboard that meets the scenario requirements, select Motherboard above the computer to switch to the motherboard view on the computer.
- g. Drag the **Motherboard**, **Socket 1151** from the Shelf to the motherboard plate in the computer case.
- 2. Connect system case connectors as follows:
  - a. Under Selected Components, select **Details** for the motherboard.
  - b. Select the **Specifications** tab.
  - c. Read the documentation to identify the location for the following connectors:
    - Power switch
    - 3-1 pin Power LED (Note: There is a spot for a 2-pin and a 3-1 pin Power LED connector on the motherboard. Make sure to use the 3-1 pin connector.)
    - Case speaker
    - HDD LED
    - Front fan
    - Rear fan
    - Main motherboard power
    - CPU power
    - USB connector
    - USB 3.0 connector
    - Front panel audio
  - d. Under Partial Connections, select the computer case. The available connectors are shown in the Selected Component window.
  - e. Under Selected Component, drag the *connector* to the port location on the motherboard. If necessary, zoom in to get a closer view of the motherboard.
  - f. Repeat step 3b until all the case connectors are connected to the motherboard.
- 3. Connect the power cables to the motherboard as follows:
  - a. Select the **power supply**.
  - b. Under Selected Component, drag the **motherboard power connector** to the port on the motherboard.
  - c. Under Selected Component, drag the CPU power cable to the port on the motherboard.