3/13/2020 Simulation Viewer

Lab Report

Your Performance

Your Score: 5 of 5 (100%) Pass Status: Pass Elapsed Time: 2 minutes 56 seconds Required Score: 100%

Task Summary

Actions you were required to perform:

- ✓ Install the video card with DVI and HDMI connectionsShow Details
- ✓ Connect the left monitor using the HDMI cable
- Connect the right monitor using the DVI-D cable
- Make the left monitor the main monitor
- Change the arrangement of the monitors

Explanation

In this lab, your task is to configure dual monitors as follows:

- Select and install a video card that provides you with dual monitor support for both monitors using a digital connection to the video card.
- Connect the left monitor to the newly installed video card using an HDMI cable. The new monitor is already plugged into the surge protector.
- Connect the right monitor to the new video card using the DVI-I cable.
- Turn on the computer.
- Turn on the new monitor.
- Make sure Extend these displays is selected.
- Configure the display properties to show the Start menu and taskbar on the left monitor.
- In the Display Properties, configure the relationship of the two monitors to reflect the physical placement of both monitors. By default, Windows places monitor 1 on the left. Because of the way monitors connect to the video adapter, this configures the monitor on the left as your right monitor.

Complete this lab as follows:

- 1. Select and install the video card as follows:
 - a. Above the right monitor, select Back to switch to the back view of the monitor and examine the available ports on each monitor.
 - b. Above the left monitor, select **Back** to switch to the back view of the monitor and examine the available ports on each monitor.
 - c. Above the computer, select **Motherboard** to switch to the motherboard view of the computer.
 - d. Select **Yes** to turn off the system.
 - e. On the Shelf, expand Video Cards.
 - f. Drag the PCIe video card with DVI-I, HDMI from the Shelf to the PCIe slot on the computer.
 - g. Select the **power supply**.
 - h. Under Selected Component, drag the 6-pin PCIe Power Supply connector into the video card.
- 2. Connect the left monitor as follows:
 - a. Above the computer, select **Back** to switch to the back view of the computer.
 - b. On the Shelf, expand Cables.
 - c. Read the **descriptions** for each cable to identify the cable to connect each monitor to the computer.
 - d. Select the **HDMI cable**.
 - e. Under Selected Component, drag a **HDMI connector** to the new video adapter in the computer.
 - f. Under Selected Component, drag the other **HDMI connector** to the HDMI port on the left monitor.
- 3. Connect the right monitor as follows:
 - a. On the computer, drag the DVI-D cable connector from the built-in connector to the new video card in the computer.
 - b. Above the computer, select **Front** to switch to the front view for the computer.

3/13/2020 Simulation Viewer

- 4. Extend the desktop to both monitors as follows:
 - a. Above the right monitor, select **Front** to switch to the front view.
 - b. Above the left monitor, select **Front** to switch to the front view.
 - c. On the left monitor, click the **power** button.
 - d. On the computer, click the **power** button.
 - Monitor 1 has the Windows taskbar, so it is the main display.
 - e. Right-click the **desktop** and select **Display settings**.
 - f. Maximize the window for easier viewing. Under Multiple displays, Extend these displays is set by default.
- 5. Make the left monitor the main monitor as follows:
 - a. Under Select and rearrange displays, select the monitor labeled 2.
 - b. Under Multiple displays, select Make this my main display. Notice that Start and the taskbar disappear.
 - c. Under Select and rearrange displays, select **Identify** to verify which screen you are on. The monitor should display a large 1.
- 6. Change the arrangement of the monitors as follows:
 - a. From the top navigation tabs, select **Office 2** to verify the main display.
 - b. On the left monitor, select Click to view Windows 10. This monitor now has the Windows taskbar, so it is the main display.
 - c. Right-click the **desktop** and select **Display settings**.
 - d. Under Select and rearrange displays, drag the **2 box** for a monitor to the left so that the main display monitor is on the left.
 - e. Select Apply.
 - f. Select **Identify** to identify the monitor you are working with (monitor 1 or monitor 2) as identified by the operating system.
 - If you have configured the monitors correctly, the Start menu and taskbar should show on the left monitor screen.