Your Performance

Your Score: 3 of 3 (100%) Pass Status: Pass Elapsed Time: 45 seconds Required Score: 100%

Task Summary

Actions you were required to perform:

- ✓ Install the i7-930 LGA1366 processor
- ✓ Install the heat sink and fan
- Plug in the fan connector

Explanation

In this lab, your task is to complete the following:

- Select the least expensive processor that is supported by the motherboard.
- Install the heat sink and fan.
- Connect the fan power cable to the motherboard.

Complete this lab as follows:

- 1. Install the least expensive processor as follows:
 - a. Above the computer, select Motherboard.
 - b. Select the motherboard.
 - c. Under Selected Component, identify the **socket type** of the motherboard.
 - d. In the Selected Component window, select **Details**.
 - e. Select the **Specifications** tab.
 - f. Read the **motherboard documentation** to identify additional requirements for the CPU.
 - g. Identify the **location** of the CPU fan connector.
 - h. Close the Motherboard Details window.
 - i. On the Shelf, expand **Processors**.
 - j. Read the **description** for each processor.
 - k. Select the **i7-930 LGA 1366 processor**.
 - l. Drag the i7-930 LGA 1366 processor to the processor socket on the motherboard.
- 2. Connect the heat sink and fan as follows:
 - a. On the Shelf, expand Fans.
 - b. Select **Details** for the heat sink and fan combination supported by the motherboard.
 - c. Select **Bottom** to view the bottom of the processor. Why is thermal paste unnecessary in this case?
 - d. Close the Heat Sink and Fan Details window.
 - e. From the Shelf, drag the Heat Sink and Fan, Socket 1366 to it's motherboard location.
 - f. In the Selected Component window, drag the fan power connector to the motherboard location.