10/15/2019 TestOut LabSim

## Lab Report: 5.1.7 Configure IP Addresses

#### **Performance**

Your Score: 2 of 2 (100%)

Elapsed Time: 4 minutes 28 seconds

### **Task Summary**

## Actions you were required to perform:

Pa Configure settings for Local Area ConnectionShow Details

Pa Configure settings for Local Area Connection 2Show Details

# **Explanation**

When configuring IP addresses, keep in mind the following:

- You cannot assign the subnet address to a host (such as 192.168.0.0 or 10.0.0.0).
- The /x notation identifies the number of bits in the subnet mask.
  - /8 indicates a subnet mask of 255.0.0.0.
  - /16 indicates a subnet mask of 255.255.0.0.
  - /24 indicates a subnet mask of 255.255.255.0.
- Portions of the subnet mask that include a 1 identify the subnet address. This portion of the address must be the same for all hosts on the subnet.
- Portions of the subnet mask that include a 0 identify the host address. This portion of the address must be unique between all hosts.
- You cannot assign the last address to a host (such as 192.168.0.255 or 10.0.255.255).

Use the following values for the TCP/IP properties in this scenario:

Connection	Host address	Subnet mask	Default gateway address	Preferred DNS server address
Ethernet	192.168.0.254	255.255.255.0	192.168.0.5	163.128.78.93 or 163.128.80.93
Ethernet 2	10.0.255.254	255.255.0.0	None	None

#### Complete this lab as follows:

- 1. In the Notification area, right-click the **Network** icon.
- 2. Select Open Network and Sharing Center.
- 3. To configure the Ethernet adapter, select **Ethernet**.
- 4. In the Ethernet Status dialog, select **Properties**.
- 5. Select Internet Protocol Version 4 (TCP/IPv4)
- 6. Select **Properties**.
- 7. Make sure that **Use the following IP address** is selected to manually configure the IP address and default gateway.
- 8. Enter the required IP address, subnet mask, default gateway, and preferred DNS server address; then select OK.
- 9. In the Ethernet Properties dialog, select Close.
- 10. In the Ethernet Status, select Close.
- 11. Select **Change adapter settings** to configure the other network adapter.
- 12. Right-click **Ethernet 2** adapter, and click **Properties**.
- 13. Repeat steps 5 through 8 to modify the TCP/IP settings for the other network adapter.